

Contents

1	Precautions before use	2
1.1	Receiving inspection	2
1.2	Storage and transportation	2
2	Normal working environment	2
3	Operation setting description	3
3.1	Breaker structure introduction	3
3.2	Breaker operation	4
4	Accessory parameter description	5
5	Trip unit introduction	8
5.1	Overview	8
5.2	HFT60-2M/2H trip unit	9
5.2.1	Interface description	9
5.2.2	Operation instruction	11
5.2.3	2M/2H protection parameter setting table	13
5.3	HFT60-3M/3H trip unit	15
5.3.1	Interface description	15
5.3.2	Operation description	16
5.3.3	Menu structure	18
5.3.4	3M/3H trip unit protection parameter setting table	26
6	Secondary wiring diagram (UEW6-2000~4000)	29
7	Installation dimension description	30
7.1	Breaker overall and installation dimension	30
7.2	Frame opening dimension	36
8	Safety distance	38
9	Installation and maintenance	39

1. Precautions before use

1.2 Receiving inspection

Inspection on the goods received. Check the UEW6 air circuit breaker (breaker for short below) model specifications and quantity with the order of goods whether they are consistent. When opening the packaging case for inspection, avoid bruising the breaker and damaging the packaging. It is recommended to keep the wooden case before installation. After receiving inspection, even if it will be installed in a very short time, please put the circuit breaker back into the package and pay attention to waterproof and moisture-proof. If any damage or abnormality is found, please contact us within 5 days after receiving the goods.

1.3 Storage and transportation

The storage environment should be dry, dust-free, and free of corrosive and explosive chemicals. Storage temperature: $-40^{\circ}\text{C} \sim +70^{\circ}\text{C}$.

Please place the breaker horizontally on fixed base. It is not allowed to be placed directly on the ground.

During storage and transportation, the breaker should be in the OFF state and the spring mechanism should be in the discharged state.

During installation and transportation, pay attention to the breaker and person protection. Tipping, striking, or falling may cause damage to the breaker.

2 Normal working environment

■ Ambient air temperature

The ambient air temperature is $-5^{\circ}\text{C} \sim +40^{\circ}\text{C}$, and the average value of 24 hours is not more than $+35^{\circ}\text{C}$.

The operating environment temperature for low temperature type breaker can be as low as -40°C .

Note: when the ambient temperature is high (more than $+40^{\circ}\text{C}$), appropriate cooling measures or derating should be taken to avoid the breaker running in high temperature for a long time and insulation aging.

■ Altitude

For normal breakers, the altitude of the site should not exceed 2500m. If the altitude above 2500m, derating should be applied.

■ Atmospheric condition

Atmospheric relative humidity should not exceed 50% at ambient air temperature $+40^{\circ}\text{C}$. At lower temperatures,

the relative humidity can be higher, for example 90% at 20°C. Special measures should be taken for the occasional condensation caused by temperature changes. There should be no corrosive or explosive chemicals around the circuit breaker.

■ Pollution degree

Breaker pollution degree: 3.

■ Protection degree

Breaker protection degree: IP40.

■ Installation category

Main circuit installation category of the breaker is IV, and the auxiliary and control circuit installation category is III.


■ Installation condition

The breaker should be installed horizontally, and the vertical gradient after installation does not exceed 5° .


3 Operation setting description

3.1 Breaker structure introduction


Fixed type



Draw out type



- | | | | |
|---------------------------------|----------------------------------|--------------------------|-------------------------|
| 1. Secondary terminal block | 5. On button | 9. Cradle | 13. Position indicator |
| 2. Trip indicator/ reset button | 6. Charged/ Discharged indicator | 10. Breaker body | 14. Crank storage space |
| 3. Charging handle | 7. Open/close indicator | 11. Stop release button | |
| 4. OFF button | 8. Trip Unit | 12. Crank inserting hole | |



- | |
|---------------------------------|
| 15. Arc chamber |
| 16. Auxiliary contacts (switch) |
| 17. Shunt trip |
| 18. Undervoltage Trip Device |
| 19. Closing electromagnet |
| 20. Secondary terminal block |
| 21. Front cover |
| 22. Operating mechanism |
| 23. Charging motor |
| 24. Cradle |

3.2 Breaker operation

Charging operation

Electric charging: When the breaker is in discharged state, if the motor is energized, it will automatically charge breaker operating mechanism. The motor will automatically stop after the charging is completed, and clicking sound can be heard, and charging state indicator indicates that it is in charged state.

Manual charging: Similarly, when the breaker is in discharged state, it can be charged by pushing down the manual charging handle. Pushing down about 6 or 7 cycles until hear the clicking sound, the reaction force of the handle is significantly reduced. At this time, the charging state indicator indicating “Charged” and the charging is completed.

Closing operation

Under charged state, press the ON button, or energize the closing electromagnet until hear the "buzz" sound, at this time, the "I/O" indicator indicates "I", and the breaker is ON. At the same time, the charging status is in "discharged". At this time, if the motor is energized, the motor will automatically charge the operating mechanism, and the motor will automatically stop after the charging is completed. The charging indicator indicating "charged".

Note: The circuit breaker can only be closed after the operating mechanism is charged.

If an undervoltage trip device is selected, the undervoltage trip device should be energized before closing the breaker.

Opening operation

In the closing state, press the OFF button on the panel, or energize the shunt release, you will hear the "buzz" sound. At this time, the "I/O" indicator window on the panel indicates "O", indicating that the breaker has been interrupted.

Note: The breaker only be opened when the breaker under ON state.

Draw out type breaker operation

In the following operation process, in the "rocked out", "test" and "rocked in" position, the red position lock button will pop up to indicate that the position is locked, and the crank cannot be turned at this time, and forced operation is not allowed. The crank is allowed to turn only when the position lock button is pressed to reset.

Connect

First pull out the left and right sliding plate on the cradle, put the circuit breaker body on the left and right sliding plate (pay attention to alignment with the body when placing), push the sliding plate into the draw out cradle, insert the crank handle into the inserting hole, press the position lock button, rotate the crank clockwise, the circuit breaker body part on the skateboard will be pushed inward from the "rocked out" position, and finally reach the "rocked in" position through the "test" position. When the "rocked in" position is reached, the red position lock button pops up, at which point you should stop rotating the handle. The busbar on the body of the breaker has been connected to the contact on the cradle, and the body and the cradle are connected.

Draw out

When the circuit breaker in the "rocked in" position, press the position locking button, rotate the crank counterclockwise, and the body of the breaker will gradually separate from the cradle. When the indicator points to the "rocked out" position, remove the crank and pull the sliding plate out (if the crank is not removed, the breaker body part cannot be removed). By holding both sides of the breaker body up, the breaker body can be removed from the cradle.

Note: 1. For the cradle of UEW6-2000, the plastic handle shown in Figure 1 should be grasped to pull out or push the left and right sliding plate. For the cradle of UEW6-3200 and UEW6-4000, the lock shown in Figure 2 needs to be first pushed back to pull or push the left and right sliding plate.




Figure 1




Figure 2

2. When the breaker body is rocked in or rocked out, the breaker must be opened first.

4 Accessory parameter description

Shunt release

Rated voltage (V)	AC220	AC380	DC110	DC220
Instantaneous current (A)	2.2	2.1	5.2	2.7
Operational voltage (V)	(0.7~1.1) U _e			
Breaking time (ms)	No more than 30ms			

Closing electromagnet

Rated voltage (V)	AC220	AC380	DC110	DC220
Instantaneous current (A)	2.2	2.1	5.2	2.7
Operational voltage (V)	(0.85~1.1) U _e			
Closing time (ms)	No more than 70ms			

Undervoltage Trip Device

Rated voltage (V)	AC220	AC380
-------------------	-------	-------

Instantaneous current (A)	0.65	0.45
Steady current (mA)	110	75
Operational voltage (V)	(0.35~0.7) Ue	
Reliable closing voltage (V)	(0.85~1.1) Ue	
Reliable non-closing voltage (V)	≤0.35Ue	
Delay time	Instantaneous, 1s, 3s, 5s	
Note: When the voltage is below 0.35Ue, the delay type under voltage release will operate instantaneously. Select a no-voltage release for power off delay		

No-voltage release

Rated voltage (V)	AC220	AC380
Instantaneous current (A)	0.65	0.45
Steady current (mA)	110	75
Operational voltage (V)	(0~0.7) Ue	
Reliable closing voltage	(0.85~1.1) Ue	
Reliable non-closing voltage	$\leq 0.35Ue$	
Delay time	1s, 3s, 5s	

Motor

Rated voltage (V)	AC220	AC380	DC110	DC220
Power consumption (VA/W)	85 (2000A frame) /110 (3200A, 4000A frame)			
Operational voltage (V)	(0.85~1.1) Ue			

Auxiliary switch

Conventional thermal current (A)	I _{th} =16A
Rated insulation voltage (V)	U _i =400V
Capacity	(2000 frame) AC-12 380V 16A, DC-12 250V 5A AC-15 400V 3A, DC-13 220V 1.2A (3200A and above)

	AC-12 400V 10A, DC-12 250V 1A
	AC-15 400V 2A, DC-13 220V 0.3A

Power module

Input voltage (V)	AC220	AC380	DC110	DC220
Output voltage (V)	DC24			


ST201 relay module

Operational voltage	DC24V
Number of contacts	3
Contact capacity	AC250V, 10A DC28V, 10A
When the trip unit DO output signal is used to control the opening and closing of the breaker or the load capacity is large, it needs to be converted by the ST201 relay module first to control.	


Cradle position electrical indication

Number of contacts	Each for rocked out, test, rocked in respectively
Contact capacity	AC380V, 2A DC250V, 0.3A

External neutral transformer

Hole size	60x20 (2000A frame) 80x30 (3200A and above) Note: The above is the standard product size. For special size, please contact us to customize.
 Front	<p>The distance between the installation point and the circuit breaker should not exceed 2m.</p> <p>When the breaker is upper incoming (that is, the upper terminal busbar of the breaker is connected to the power side, and the lower terminal busbar is connected to the load side), when the external neutral transformer passes through the N line, its front side faces the power side and the reverse side faces the load side. When the circuit breaker is lower incoming (that is, the lower terminal busbar is connected to the power side and the upper terminal busbar is connected to the load side), when the external neutral transformer passes through the N line, the reverse side of the breaker faces the power side and the front side faces the load side.</p>

Residual current transformers

Hole size	115x280
	When residual current protection is needed, please select residual current transformer.

Opening lock

Lock the breaker in the OFF position to ensure that it cannot be closed. When locking, press down the ON button and rotate the key about 90 degrees counterclockwise and pull out the key. When unlocking, insert the key clockwise about 90 degrees to unlock. At this time, the key cannot be pulled out.

One lock and one key: one breaker with one lock and one key

Two locks and one key: two breakers with two same locks and one key

Three locks and two keys: three breakers with three same locks and two keys

Five locks and three keys: Five breakers with five same locks and three keys

Five locks and three keys (Three incoming lines and two busbar) : Special five locks and three keys, used in three incoming lines and two busbar system

5 Trip Unit introduction

5.1 Overview

To ensure the reliable operation of the trip unit, the trip unit is supplied with power in the following two ways:

- by power transformer supply

When the rated current is greater than 400A, the trip unit can work normally when the primary single-phase current is not less than $0.8I_n$, and the three-phase current is not less than $0.4I_n$.

- Auxiliary power supply

Allowable range for DC24V: $\pm 5\%$;


Allowable range for AC220V/AC380V, DC110V/DC220V: 15%.

Rated power consumption: <7W

There is a red reset button on the upper side of the trip unit. When the trip unit trip for protection, the reset button will pop out. The breaker can only close after it is pressed down.

5.2 HFT60-2M/2H trip unit

5.2.1 Interface description



Display window indicator description

The display data in the function window and ammeter window are combined with different indicator and their combinations to indicate different power parameters. The details are shown in the following table.

Indicator	Meaning
V1, V2, V3+VN+V	Voltages of phase A, phase B, and phase C
V1, V2, V3 +V	Line voltage of phase AB, BC, and CA
Hz	Frequency
cos Φ	Power factor
kW indicator on	Power
kW indicator flash	kWh of power
L1, L2, L3, N+ A/kA	Current of phase A, phase B, phase C, and phase N
L1, L2, L3 + δ +%	Current imbalance rate of phase A, phase B and phase C
%	Contact wear value
X10	Cycles of the breaker opening and closing
If+A/kA	Grounding current
A/kA indicator flash	The unit of the display value is kA
A/kA indicator on	The unit of the display value is A

Note: If the above indicator is not specifically described, the indicator is on.

Protection type Indicator description

When the trip unit is faulty, the I_{c1} , I_{c2} , δ , If, L, S, I, and T indicators flash, indicating load monitoring 1, load monitoring 2, current imbalance, grounding or leakage, overload long delay, short current short delay, short current instantaneous, and self-diagnosis fault respectively.

When T indicator is on, a self-check fault occurs and the fault code is displayed. The fault code is as follows:

ER01	ER02	ER03	ER04	ER05
E ² PROM error	A/D error	Environmental overheating	CT1 disconnected	CT2 disconnected
ER06	ER07	ER11	ER12	ER13
CT3 disconnected	CT3 disconnected	Tripping coil	Breaker not tripping.	Contact maintenance

		disconnected		indication
--	--	--------------	--	------------

When the trip unit is in the parameter setting state, the indicator combination indicates the current setting items as shown in the following table.

Indicator	Meaning
Ic1+ A/kA	Load monitoring 1 current setting value
Ic1+ S	Load monitoring 1 Time setting value
Ic2+ A/kA	Load monitoring 2 current setting value
Ic2+ S	Load monitoring 2 time setting value
N	N-phase protection current setting value
δ +%	Current imbalance protection setting value
δ +S	Current imbalance time setting value
If+A/kA	Grounding or leakage current setting value
If+S (flash)	Inverse time shear factor of grounding
If+S (ON)	Grounding or leakage time setting value
L+A/kA	Overload long delay current setting value
L+S	Overload long delay time setting value
S on +A/kA	Short-circuit short delay inverse time current setting
S flash +A/kA	Short-circuit short delay fixed time current setting
S+S	Short circuit short delay time definite time delay time set value
I+A/kA	Short-circuit instantaneous current setting value
L1	Trip unit address number 1-255
L2	The baud rate of the trip unit, 9.6K or 19.2K

Note: If the above indicator is not specifically described, the indicator is on except A/kA. A/kA flashing indicates that the unit of display value is kA, and being on indicates that the unit of display value is A

Description of the working status indicator

Rx flashing indicates that the trip unit is receiving data. Tx flashing indicates that the trip unit is sending data.

The “Running” indicator flashing indicates the trip unit is energized to work.

The "Setting" indicator flashing indicates that the trip unit is in the setting state. At this time, you can select the item to be set by the "▲" and "▼" keys. If the Settings indicator is on, it indicates that the parameter setting state of a specific item is entered. You can modify the related settings.

If the “Check” indicator is on, the trip unit is in the fault checking state. In this case, you can check the parameters of the last fault.

If the “TEST” indicator is on, it indicates that the trip unit is in the test state. In this case, the trip unit can be

tested for instantaneous trip.

If the "STORAGE" indicator is on for a while, one parameter setting is saved.

If the "FAULT" indicator is on, it indicates that the trip unit is in the fault trip state. The protection indicator is indicating the corresponding fault type.

If the "ALARM" indicator flashes, the trip unit detects a grid fault. The protection indicator indicates the corresponding fault type.

5.2.2 Operation instruction

When the trip unit is in normal operation state, the three-phase line voltage, three-phase phase voltage, frequency, power factor, active energy and active power, three-phase(four-phase) current, etc. are in loop display (if the corresponding function is selected). Press the "▲" and "▼" keys to select and position the above parameters. Press the "▲", "▼" key once, the display changes once, press the "RESET" key to exit.

Through "RESET", "CHECK", "ENTER", "SET", "CLEAR", "TEST", "▲", "▼" key of the operation area, you can set, check, trip test and operate other functions.

Protection parameter setting

When setting the setting values of various protection characteristics, it should be guaranteed that $I_i > I_{sd} > I_r$ (if the I_{sd} definite time limit and inverse time limit protection are both turned on, the definite time current setting value should be greater than the inverse time current setting value, otherwise the inverse time limit will automatically fail), and the operation steps are as follows:

Step 1: Confirm that the trip unit is in the normal operating state. If the trip unit is in other states, press the "RESET" key until the current display window is in the loop display state.

Step 2: Press the "Set" key, then the settings indicator flashes.

Step 3: Select the protection type by the "▲" and "▼" keys. Select the setting type and press the "ENTER" key again. When the Setting indicator is on, it indicates that the setting state of the specific protection parameters is entered. You can use "▲" and "▼" keys to set parameters.

Step 4: After the parameter setting is completed, press the "ENTER" key, at this time, the STORAGE indicator is on, indicating that the modified data has been saved (if you do not want to save, you can directly press the "RESET" key to restore the original value, at this time, the SET indicator will resume flashing, and select other items through the "▲" and "▼" keys or "ENTER" keys to reset the parameters).

Step 5: Press the "RESET" key to exit the setting interface of the item, and the "Setting" indicator will flash again. Repeat step 3 until all values have been modified. Press the "RESET" key to exit the setting function.

Tripping test

Step 1: Confirm that the trip unit is in the normal operating state. If the trip unit is in other states, press the "RESET" key until the current display window is in the loop display state.

Step 2: Press the "Test" key, at this time the TEST indicator is on, press the "ENTER" key, the breaker is opened, and the ammeter display window displays the operation cycle. (Re-close the circuit breaker and press the "ENTER" key again. The breaker will re-open.)

Step 3: Press "RESET" key, "Test" indicator is off and exits testing.

Historical fault checking

The trip unit stores the last fault record. Specific checking operations are as follows:

Step 1: Confirm that the trip unit is in the normal running state. If the trip unit is in other states, press the "RESET" key until the current display window is in the loop display state.

Step 2: Press the "Check" key. At this time, the Checking indicator and FAULT indicator are on, and the corresponding fault type indicator is on. The trip unit repeatedly displays the fault current and time. Press the "▲" and "▼" keys to view other data when the fault occurs. Press the "Reset" key, and the trip unit display the fault current and time again.

Step 3: Press the "Reset" key until the Checking indicator and "FAULT" indicator are off to exit the historical fault checking state.

Display and operation after fault operation

1. Trip fault

After the trip unit trips due to a fault, the fault current and time are loop displayed on the trip unit. The "FAULT" indicator and the corresponding protection type indicators are on. Press the "▲" and "▼" keys to view other data when the fault occurs. You can press the "Reset" key to exit the checking state and return to the fault display state. Press the "CLEAR" key, and the trip unit displays resetting and exits the fault display state.

2. Self-diagnosis fault

The self-diagnosis function of the trip unit is used to detect the working state and operating environment of the controller itself. When a self-diagnosis fault occurs on the trip unit, the T indicator will be on. Press "ENTER" to display the fault code. If the fault has been cleared, press the "CLEAR" key to clear the self-diagnosis fault "T" indicator and restore to normal state. If there are several diagnostic faults, press the "▲", "▼" keys to view the fault codes. The fault codes are as follows:

ER01	ER02	ER03	ER12	ER13
------	------	------	------	------

E ² PROM error	A/D error	Environmental overheating	Breaker not tripping	Contact maintenance indication
---------------------------	-----------	---------------------------	----------------------	--------------------------------

5.2.3 2M/2H protection parameter setting table


Overload long delay										
Setting current I _{r1} (tolerance ±10%)			(0.4 ~ 1.0)×I _n +OFF (step size: 1A)							
<div>Operation time</div> <div>(tolerance ±15%)</div> <div>$Tr = \frac{K}{(N^2 - 1)}$</div>	Current	Operating time								
	I _r	≤1.05	No operating in two hours							
		>1.2I _r	Operate in one hour							
	Setting time t _L (Factor K in parentheses)									
	1.5 I _r	8(10)	12.8(16)	19.2(24)	32(40)	48(60)	64(80)	80(100)	108(135)	
		144(180)	224(280)	320(400)	480(600)	640(800)	800(1000)	960(1200)	1040(1300)	
	2.0I _r	3.32(10)	5.32(16)	8.00(24)	13.32(40)	20(60)	26.6(80)	33.3(100)	45(135)	
		60(180)	93.3(280)	133(400)	200(600)	266(800)	333(1000)	400(1200)	433(1300)	
	7.2I _r	0.19(10)	0.32(16)	0.47(24)	0.79(40)	1.7(60)	1.57(80)	1.97(100)	2.66(135)	
		3.54(180)	5.51(280)	7.87(400)	11.8(600)	15.7(800)	19.7(1000)	23.6(1200)	25.6(1300)	
Note: N=I/I _r (I is the actual fault current and I _r is the overload current setting value). The setting time displayed by the trip unit is the actual operating time when I=2I _r . With the increase of current I, the operating time will shorten accordingly, which can be calculated according to the formula										
Thermal memory			30min+OFF(can be eliminated by deenergized)							
Short-circuit short delay										
Setting current I _{r2} (tolerance ±10%)			(1.5 ~ 15)×I _r +OFF (step size: 1A)							
Setting time t _s (s) (tolerance ±15%)			0.1 ~ 1s (step size: 0.1s)							
Inverse time limit operating time			The curve is the same as the overload long delay curve, and the curve speed is 10 times faster than that of the overload long delay.							

	The time calculated by the delay curve formula divided by 10 is the short delay inverse time delay time												
Thermal memory	30min+OFF (can be eliminated by deenergized)												
Note: When the inverse time limit and definite time limit protection are on, the inverse time limit current setting value must be less than the definite time limit current setting value, otherwise the inverse time limit function automatically fails, and the actual delay time is not less than the set time of the definite time limit													
Short circuit instantaneous													
Setting current Ir3 (tolerance ±10%)	$I_n \sim 50kA+OFF$ ($I_n < 3200A$) $I_n \sim 70kA+OFF$ ($I_n=3200A$) $I_n \sim 100kA+OFF$ ($I_n > 3200A$)												
Tripping time	within 30ms												
Ground protection													
) Setting current If (tolerance ±10%)	$(0.2 \sim 1) \times I_n+OFF$ (min. 100A)												
Definite time limit setting time tg (s) (tolerance ±15%)	00.1 ~ 1s+OFF(step size 0.1s OFF indicates only alarm not tripping)												
Inverse time shear factor Cr	1.5 ~ 6+OFF (step size 0.1s OFF indicates inverse time off)												
Inverse time limit operating time	。 Formula $t=tg \times Cr \times I_g / I$ t - Delay time Tg - set delay time Cr - shear factor Ig - setting operating current I - Grounding current. When the multiple of fault current (I/If) is less than Cr, the operating characteristic is inverse time limit; when the multiple of fault current is greater than or equal to Cr, the operating characteristic is definite time limit.												
Residual current protection													
Setting current Ig (tolerance 10%)	0.5A~30A+OFF (Step size 0.1A)												
Setting time tg (tolerance 10%)	instantaneous	0.06	0.08	0.17	0.25	0.33	0.42	0.5	0.58	0.67	0.75	0.83	
Multiple of fault current	Maximum tripping time												
If	0.04	0.36	0.5	1	1.5	2	2.5	3	3.5	4	4.5	5	
2If	0.04	0.18	0.25	0.5	0.75	1	1.25	1.5	1.75	2	2.25	2.5	
5If~10If	0.04	0.072	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	
Neutral pole protection													
Setting current Ig (tolerance ±10%)	$(0.5, 1) \times I_n+OFF$												

Operating time	Same as overload Long delay
Current imbalance protection	
Imbalance rate δ setting range	(40% ~ 100%) +OFF
Delay time	0.1 ~ 1s+OFF (step size 0.1s OFF indicates alarm not tripping)
Load monitoring	Mode 1, Mode 2
Mode 1	
Load 1 Unload current	(0.2~1) In+OFF (OFF indicates exit, minimum 100A)
Setting time (inverse time limit, the operating characteristics are the same as the overload long delay)	Same as the time setting table for overload long delay
Load 2 Unload current	(0.2~1) In+OFF (OFF indicates exit, minimum 100A)
Setting time (inverse time limit, the operating characteristics are the same as the overload long delay)	Same as the time setting table for overload long delay
Mode 2	
Load 1 Unload current	(0.2~1) In+OFF (OFF indicates exit, minimum 100A)
Setting time (inverse time limit, the operating characteristics are the same as the overload long delay)	Same as the time setting table for overload long delay
Load 1 Return current	(0.2~1) In+OFF (OFF indicates exit, minimum 100A)
Return time	Fixed 60s

5.3 HFT60-3M/3H trip unit

5.3.1 Interface Description



1. Model

2. Rated current

3. Display

4. Indicator of protection category and operation status

5. Operation keys

Indicator

- Communication Indicator: When there is data interaction between the trip unit and the host computer, the indicator flashes.

- Operation Indicator: The green LED always flashes as long as the trip unit is energized and the working status is normal.
- AP Indicator: The indicator flashes when the advanced protection fault trips. (e.g. phase loss, over voltage, voltage imbalance, under frequency, over frequency, phase sequence, inverse power and other faults trip. If the protection is set to only alarm and do not trip, when a fault occurs, the "ALARM" indicator will be on).
- L, S, I and If protection type indicator: The corresponding LED flashes to indicate the type of fault: when there' s fault trip. When the protection parameter is set, the LED indicator indicates the currently set items (L: overload long time delay protection; S: short circuit short time delay protection; I: short circuit instantaneous protection; If: grounding or residual current protection).
- Fault indicator: The indicator flashes when there' s a fault trip.
- ALARM indicator on: The indicator is on when there' s an fault alarm.

Operation Keys


- "Reset" key: Exit the current menu and enter the previous menu, or cancel the setting of the current parameter.
- " Check" key: Pressing the "Check" key will cycle between the "System Parameter Setting" theme menu and the "History and Maintenance" theme menu (in the password input interface, it is the "right" key).

- ENTER key: Enter the next menu pointed by the current item, or select the current parameter and store the modification.
- (Up) ▲ key: Move upward in the menu, or select upward parameter.
- Set key: Press the set key to loop between the "Measure" menu and the "Protection Parameter Setting" menu (in the password input interface, it is the "left" key).
- (Down) ▼ key: Move downward in the menu, or select downward parameter.
- TEST key: Press it for one trip, used to test whether the mechanical is normal or not.
- Clean key: Fault reset key. The fault is displayed if there' s a fault trip. After troubleshooting, this key need to be pressed to reset the display.

5.3.2 Operating Instructions


Providing 4 theme menu and a default interface

- Default interface




Displaying a bar graph of the current of each phase when no other function is active

- Measurement menu




Press the "Set" key to enter the measurement menu. If there is no other operation, the system will return to the default interface in a few minutes. Press the "Reset" key to return to the default interface

●System parameter setting menu




Press the "Check" key to enter the system parameter setting menu. If there is no other operation, the system will return to the default interface in a few minutes, press the "Reset" key to return to the default interface

●Protection parameter setting menu



Press the "Set" key (twice) to enter the protection parameter setting menu. If there is no other operation, the system will return to the default interface in a few minutes. Press the "Reset" key to return to the default interface.

● History and maintenance menu



Press the "Check" key (twice) to enter the history and maintenance menu. If there is no other operation, the system will return to the default interface in a few minutes. Press the "Reset" key to return to the default interface.

▲, ▼

Example of sub-menu operation (taking overload long time delay protection current setting as an example)

Press "Set" key twice to enter the protection parameter setting menu. Select "Current Protection" by ▲, ▼ keys and press "ENTER" key to enter. Select "Long time Delay" by ▲, ▼ keys and press "ENTER" to enter. Select "Current Setting Value" ▲, ▼ keys and press "ENTER" to enter. Adjust the current level by ▲, ▼ and press "ENTER" to save. Similarly, the curve type and time of delay can be selected by ▲, ▼ keys and "ENTER" key.

5.3.3 Menu structure

The menu consists of five main parts: the measurement menu, the parameter setting menu, the protection parameter setting menu, history and maintenance menu, and advanced menu.






Note: The actual menu changes accordingly depending on the function selected by the user.



1 Measurement menu structure:





Level-1 menu	Level-2 menu	Level-3 menu	Level-4 menu	Level-4 menu
Current I	Instantaneous value	I_a, I_b, I_c, I_n	$I_a =$ 0A	
			$I_b =$ 0A	
			$I_c =$ 0A	
			$I_n =$ 0A	
			$I_g =$ 0A or $I_{\Delta n} =$ 0.00A	
	Maximum value		$I_a =$ 0A	
			$I_b =$ 0A	
			$I_c =$ 0A	




			$I_n = 0A$	
			$I_g = 0A$ or $I_{\Delta n} = 0.00A$	
			Reset (+/-)	
		Imbalance rate	$I_a = 0\%$	
			$I_b = 0\%$	
			$I_c = 0\%$	
	Current thermal capacity	100%		
	Required value	$\overline{I_a}, \overline{I_b}, \overline{I_c}, \overline{I_n}$	60min	
			$\overline{I_a} = 0A$	
			$\overline{I_b} = 0A$	
			$\overline{I_c} = 0A$	
			$\overline{I_n} = 0A$	
		Maximum value	5min	
			$\overline{I_a} = 0A$	
			$\overline{I_b} = 0A$	
			$\overline{I_c} = 0A$	
			$\overline{I_n} = 0A$	
			Reset (+/-)	
Voltage U	Instantaneous value	$U_{ab} = 0V$		
		$U_{bc} = 0V$		
		$U_{ca} = 0V$		
		$U_{an} = 0V$		
		$U_{bn} = 0V$		
		$U_{cn} = 0V$		

	Average value	U _{av} =380V		
	Imbalance rate	0%		
	Phase sequence	A, B, C		
Frequency F	50Hz			
Electricity E	Total electricity	E _P = 0kWh		
		E _Q = 0kvarh		
		E _S = 0kVAh		
	Input electricity	E _P = 0kWh		
		E _Q = 0kvarh		
	Output electricity	E _P = 0kWh		
		E _Q = 0kvarh		
	Electricity reset	Reset/Cancel		
Power P	Instantaneous value	P, Q, S	P = 0kW	
			Q = 0kvar	
			S = 0kVA	
		Power factor	1.00	
			Compatibility	
			P _{Fa} = 1.00	
			P _{Fb} = 1.00	
			P _{Fc} = 1.00	
		P _a , Q _a , S _a	P _a = 0kW	
			Q _a = 0kvar	
			S _a = 0kVA	
		P _b , Q _b , S _b	P _b = 0kW	
			Q _b = 0kvar	
			S _b = 0kVA	

	Required value	P_c, Q_c, S_c	$P_c =$ 0kW	
			$Q_c =$ 0kvar	
			$S_c =$ 0kVA	
		$\overline{P}, \overline{Q}, \overline{S}$	$\overline{P} =$ 0kW	
			$\overline{Q} =$ 0kvar	
			$\overline{S} =$ 0kVA	
		Maximum value	$\overline{P} =$ 0kW	
			$\overline{Q} =$ 0kvar	
			$\overline{S} =$ 0kVA	
			Reset (+/-)	
Harmonic wave H	Wave form	I_a, I_b, I_c, I_n	I_a	
				
			I_b	
				
		U_{ab}, U_{bc}, U_{ca}	I_c	
				
		U_{ab}, U_{bc}, U_{ca}	I_n	
				
		U_{ab}, U_{bc}, U_{ca}	U_{ab}	
				

			U_{bc} 	
			U_{ca} 	
	Fundamental wave	I(A)	$I_a = 9999A$	
			$I_b = 9999A$	
			$I_c = 9999A$	
			$I_n = 9999A$	
		U(V)	$U_{ab} = 9999V$	
			$U_{bc} = 9999V$	
			$U_{ca} = 9999V$	
			$U_{an} = 9999V$	
			$U_{bn} = 9999V$	
			$U_{cn} = 9999V$	
	THD	I(%)	$I_a = 20.0\%$	
			$I_b = 20.0\%$	
			$I_c = 20.0\%$	
			$I_n = 20.0\%$	
		U(%)	$U_{ab} = 20.0\%$	
			$U_{bc} = 20.0\%$	
			$U_{ca} = 20.0\%$	
			$U_{an} = 20.0\%$	
			$U_{bn} = 20.0\%$	
			$U_{cn} = 20.0\%$	

	thd	I(%)	$I_a = 20.0\%$	
			$I_b = 20.0\%$	
			$I_c = 20.0\%$	
			$I_n = 20.0\%$	
		U(%)	$U_{ab} = 20.0\%$	
			$U_{bc} = 20.0\%$	
			$U_{ca} = 20.0\%$	
			$U_{an} = 20.0\%$	
			$U_{bn} = 20.0\%$	
			$U_{cn} = 20.0\%$	
	FFT	I(3,5,7...31)	$I_a(3,5,7...31)$	I_a FFT THD= 0.0% 
			$I_b(3,5,7...31)$	I_b FFT THD= 0.0% 
			$I_c(3,5,7...31)$	I_c FFT THD= 0.0% 
			$I_n(3,5,7...31)$	I_n FFT THD= 0.0% 

		U(3,5,7...31)	U _{ab} (3,5,7...31)	U _{ab} FFT THD= 0.0% 
			U _{bc} (3,5,7...31)	U _{bc} FFT THD= 0.0% 
			U _{ca} (3,5,7...31)	U _{ca} FFT THD= 0.0% 

2 System parameter setting menu structure:

Level-1 menu	Level-2 menu	Level-3 menu	Level-4 menu	Level-4 menu
Clock setting	Date	=2004/11/15		
	Time	=19: 50: 35		
Gauge setting	System type	=34W 4CT		
	Connection mode	=Upper incoming connection		
	Power direction	=P+		
	Current required	Calculation mode	=Algorithm	
		Time window type	=Sliding	
		Selection time	=60min	
	Power required	Calculation mode	=Algorithm	
		Time window type	=Sliding	

		Selection time	= 60min	
Test & lock	Test trip	Test type	=Three-stage protection	
		Test parameter	=I: 9999A	
		Test control	=Start	
	Remote lock	Remote lock	=Unlock	
	Parameter lock	Parameters are locked	Parameter lock =Lock	
		(Input) User password =0000	User password (Change) =0000	
Communication setting	Address	=3		
	Baud rate	=9.6K		
I/O setting	Function setting	=Regional interlock =ZSI		
	Operation mode	=DO1 =Normally open Pulse =N/O Pulse =360S		
	I/O Status	I/O Status DO1 DO2 DO3 DI1 1 1 1 1		

3 Protection parameter setting menu structure:

Level-1 menu	Level-2 menu	Level-3 menu	Level-4 menu	Level-4 menu
Current protection	Long time delay	I _r	Example: =2500A=100%I _n	
		Curve Type	Example: =SI	
		Time of delay	Example: =C16, 86.0S@1.5I _r	

		Cooling time	Example: =3h	
	Short time delay	Definite time limit	Operating current	Example: =5000A=2.0I _r
			Time of delay	Example: =0.1S
		Inverse time limit	Operating current	Example: =5000A=2.0I _r
			Time of delay	Example: C16,1.92s@6I _r
	Instantaneous	Operating current	Example: =25000A=100%I _n	
	I Imbalance	Operation mode	Example: =Alarm	
		Start value	Example: =30%	
		Start time	Example: =1.0s	
		Return value	Example: =10%	
		Return time	Example: =10.0s	
	Neutral-phase protection	Neutral-phase protection	Example: =200%	
	Current required	$\overline{I_a \text{ max}}$ $\overline{I_b \text{ max}}$ $\overline{I_c \text{ max}}$ $\overline{I_n \text{ max}}$	Operation mode	Example: =Alarm
			Start value	Example: =2000A
			Start time	Example: =15s
			Return value	Example: =1800A
			Return time	Example: =15s
	Grounding protection	Operating current	Example: =2500A	
		Time of delay	Example: =0.4s	
		Grounding factor	Example: =6.0	
	Grounding Alarm	Start current	Example: =2000A	
		Start time	Example: =0.1s	
		Return current	Example: =1000A	
		Return time	Example: =0.1s	
	Residual current protection	Operating current	Example: =8.0A	
		Time of delay	Example: =0.75s	

	Residual current alarm	Start current	Example: =5.0A
		Start time	Example: =0.1s
		Return current	Example: =4.0A
		Return time	Example: =0.1s
Load monitor	Operation mode	Example: =I Mode 1	
	Unloading value 1	Example: =800	
	Unloading time 1	Example: =50% t_r	
	Unloading value 2	Example: =700A	
	Unloading time 2	Example: =25% t_r	
	Operation mode	Example: =P Mode 2	
	Unloading value 1	Example: =299kW	
	Unloading time 1	Example: =10s	
	Restore value	Example: =300kW	
	Restore time	Example: =3600s	
Voltage protection	Under voltage	Operation mode	Example: =Alarm
		Start value	Example: =100V
		Start time	Example: =0.2s
		Return value	Example: =90V
		Return time	Example: =60.0s
	Over voltage	Operation mode	Example: =Alarm
		Start value	Example: =600V
		Start time	Example: =0.2s
		Return value	Example: =100V
		Return time	Example: =60.0s
	U imbalance	Operation mode	Example: =Alarm
		Start value	Example: =60%

		Start time	Example: =0.2s
		Return value	Example: =30%
		Return time	Example: =60.0s
Other protection	Under frequency	Operation mode	Example: =Alarm
		Start value	Example: =45.0Hz
		Start time	Example: =0.2s
		Return value	Example: =50.0Hz
		Return time	Example: =36.0s
	Over frequency	Operation mode	Example: =Alarm
		Start value	Example: =65.0Hz
		Start time	Example: =0.2s
		Return value	Example: =50.0Hz
		Return time	Example: =36.0s
	Phase sequence	Operation mode	Example: =Trip
		Start value	Example: =A, B, C
	Inverse power	Operation	Example: =Alarm
		Start value	Example: =500kW
		Start time	Example: =0.2s
		Return value	Example: =50kW
		Return time	Example: =360s
	Communication failure	Operation	Example: =Alarm
		Link time-out	Example: =200s

4 History and maintenance menu structure:

Level-1 menu	Level-2 menu	Level-3 menu	Level-4 menu	Level-4 menu
Current Alarm	Example: Phase sequence alarm, inverse power alarm, over frequency alarm.....			

Number of operation cycles	Total number cycles	Example: 300		
	Number of operation cycles	Example: 219 (ENTER key reset)		
Contact wear	Total wear	Example: 120		
	Contact wear	Example: 20 (ENTER key reset)		
Product Information				
Trip record	Example: 1 Under voltage tripping 2004/06/17	Under voltage tripping		
		T= 0.20S		
		U _{max} = 0V		
		11:24:59 6/17		
		F = 0.00Hz		
		U _{ab} = 0V		
		U _{bc} = 0V		
		U _{ca} = 0V		
		
	Example: 8 Short circuit definite time limit 2004/05/30	A phase short circuit definite time limit		
T= 0.4S				
I= 4300A				
15:28:25 5/30				
	I _a = 4300A			
	I _b = 4200A			
	I _c = 4000A			
	I _n = 4150A			

Alarm record	Example: 1 Communication failure alarm 2004/07/16	Communication failure alarm 2004/07/16 20:38:45		
		
	Example: 8 Under voltage alarm 2004/06/20	Under voltage alarm U _{max} = 0V 2004/06/20 22:29:40		
Deflection record	Example: 1 Local closing 2002/06/18	Local closing 2002/06/18 9:30:56		
		
	Example: 8 Fault trip 2002/06/12	Fault trip 2002/06/12 10:15:52		

5.3.4 Protective parameter setting table for 3M/3H type controllers

Overload long time delay									
Setting current I_{r1} (tolerance $\pm 10\%$)		(0.4~1.0) $\times I_n$ +OFF (step size: 1A)							
Operating time (tolerance $\pm 15\%$)	Current	Operating time							
	$\leq 1.05I_r$	No trip within 2 hours							
	$> 1.2I_r$	Trip within 1 hour							
	Curve type	Setting time t_r (Factor K in parentheses)							
	Standard inverse time limit	0.61(0.	0.98(1	1.47(0.0	2.46(0.	3.68(0	4.91(0.	6.14(0.0	8.29(0.007

The factory default curve for trip unit is curve 3	$T=K/(N^{0.02}-1)$	005)	.0)	12)	02)	.03)	04)	5)	5)
		11.1(0.09)	17.2(0.14)	24.6(0.2)	36.8(0.3)	49.1(0.4)	61.4(0.5)	73.7(0.6)	86(0.7)
	Fast inverse time limit $T=K/(N-1)$	2(1)	3.2(1.6)	4.8(2.4)	8(4)	12(6)	16(8)	20(10)	27(13.5)
		36(18)	56(28)	80(40)	120(60)	160(80)	200(100)	240(120)	280(140)
	Super fast inverse time limit (general purpose)	8(10)	12.8(1.6)	19.2(24)	32(40)	48(60)	64(80)	80(100)	108(135)
	$t=K(N^2-1)$	144(180)	224(80)	320(400)	480(600)	640(800)	800(1000)	960(1200)	1040(1300)
	Super fast inverse time limit (motor protection)	6.22(10)	9.96(1.6)	14.9(24)	24.9(40)	37.3(60)	49.8(80)	62.2(100)	84(135)
	$T=(K/1.15) \times \log_e[N^2(N^2-1.15)]$	112(180)	174(80)	249(400)	373(600)	498(800)	622(1000)	747(1200)	871(1300)
	Compatible with high voltage fuse	2.46(10)	3.94(1.6)	5.9(24)	9.85(40)	14.8(60)	19.7(80)	24.6(100)	33.2(1300)
	$T=K/(N^4-1)$	44.3(180)	69.8(80)	98.5(400)	147(600)	197(800)	246(1000)	295(1200)	344(1300)
	Normal inverse time limit (I^2T)	15(15)	30(30)	60(60)	120(120)	240(240)	360(360)	480(480)	600(600)
	$T=(1.5/N)^2 \times K$	720(720)	840(840)	960(960)					


Note: $N=I/I_r$ (I is the actual fault current, I_r is the set value of overload current). The set time displayed by in the trip unit is the actual operation time when $I=1.5I_r$, with the increase of current I , the operation time is shortened accordingly, which can be calculated according to the formula

Thermal memory	30min+OFF (can be cleared after power off)
Short circuit short time delay	
Setting current I_s (tolerance $\pm 10\%$)	$(1.5 \sim 15) \times I_r + \text{OFF}$ (step size 1A) $(1.5 \sim 15) \times I_r + \text{OFF}$ (step: 1A)
Definite time limit fixing time t_s (s) (tolerance $\pm 15\%$)	0.1 ~ 0.4s (step size 0.1s) 0.1 ~ 0.4s (step: 0.1s)
Inverse time limit operation time	The curve is the same as the overload long-delay curve, the curve speed is 10 times faster than the overload long time delay. The time calculated according to the delay curve formula is divided by 10, which is the short time delay inverse time limit time

	of delay.												
Thermal memory	30min+OFF (can be cleared after power off)												
Note: When both inverse time limit and definite time limit protection are on, the setting value of inverse time limit current must be less than the setting value of definite time limit current, otherwise the function of inverse time limit will be failed automatically, in addition, the actual time of delay is not less than the setting time of definite time limit													
Short circuit instantaneous													
Setting current $I_{\Delta 3}$ (tolerance $\pm 10\%$)	$(1\sim 20) \times I_n + \text{OFF}$ (step size: 1A)												
Trip time	Within 30ms												
Grounding protection													
Setting current I_f (tolerance $\pm 10\%$)	$(0.2 \sim 1) \times I_n + \text{OFF}$ (Min 100A)												
Definite time limit setting time t_g (s) (tolerance $\pm 15\%$)	0.1 ~ 1s (Step size: 0.1s)												
Inverse time shear factor C_r	1.5 ~ 6+OFF (Step size: 0.1s OFF means inverse time off)												
Inverse time action time	Formula $t = t_g \times C_r \times I_g / I$ - Delay time T_g - Set delay time C_r - Shear factor I_g - Set action current I - Ground current. When the multiple of fault current (I/I_f) is less than C_r , the action characteristic is inverse time characteristic. When the multiple of fault current is greater than or equal to C_r , the action characteristic is definite time characteristic.												
Grounding alarm (grounding alarm and grounding protection are independent of each other, with independent parameter settings, and can exist simultaneously)													
Alarm operation setting value	Current $(0.2 \sim 1) \times I_n + \text{OFF}$												
	Time 0.1 ~ 1s (Step size: 0.1s)												
Alarm end set value	Current $(0.2 \sim 1) \times I_n$												
	Time 0.1 ~ 1s (Step size: 0.1s)												
Residual current protection													
Setting current I_g (with a tolerance of 10%)	0.5A~30A+OFF (Step size 为 0.1A)												
Setting time t_g (with a tolerance of 10%)	Instantaneous	0.06	0.08	0.17	0.25	0.33	0.42	0.5	0.58	0.67	0.75	0.83	

Fault current multiple	Maximum tripping time (s)											
If	0.04	0.36	0.5	1	1.5	2	2.5	3	3.5	4	4.5	5
2If	0.04	0.18	0.25	0.5	0.75	1	1.25	1.5	1.75	2	2.25	2.5
5If~10If	0.04	0.072	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
Neutral pole protection												
Setting current In (tolerance ± 10%)	(0.5, 1) ×In+OFF											
Operating time	Same as overload long delay											
Current imbalance protection												
Protection setting value	5% ~ 60%											
Delay Time	0.1 ~ 40s (Step size.0.1s)											
Protection return set value	5% ~ start value%					This setting is only available when the operation mode is alarm						
Time	10 ~ 200s (Step size0.1s)											
Operation mode	Trip, alarm, Shut down											
Load monitor	1. Current mode 1 2. Current mode 2 3. Power mode 1 4. Power mode 2 5. Shutdown											
Setting value of unloading I action	0.2~1.0Ir (current mode 1/2)											
	200~10000kW (power mode 1/2)											
Unloading I action delay	20%~80%tr (Current mode 1/2)											
	10~3600s (Power mode 1/2)											
Setting value of unloading II action	0.2~1.0Ir (current mode 1), 0.2I~unloading value (current mode 2)											
	200~10000kW (power mode 1), 100~unloading value (power mode 2)											
Unloading II action delay	20%~80% tr (current mode 1), 10~600s (current mode 2)											
	10~3600s (power mode 1/2)											
Voltage imbalance protection												
Protection setting value	2%~30%											
setting time	0.2~60s											
Protection return set value	2%~Start value					This setting value is only available when the						

setting time	0.2~60s	operating mode is "alarm"
Operating mode	Alarm/Trip/Shutdown	
Undervoltage protection		
Protection setting value	100V~return value	
setting time	0.2~60s	
Protection return set value	Starting value~1200V	This setting value is only available when the operating mode is "alarm"
setting time	0.2~60s	
Operating mode	Alarm/Trip/Shutdown	
Overvoltage protection		
Protection setting value	Return valute~1200V	
setting time	0.2~60s	
Protection return set value	100V~return value	
setting time	0.2~60s	
Operating mode	Alarm/Trip/Shutdown	
Low frequency protection		
Protection setting value	45Hz~returen value	
setting time	0.2~5s	
Protection return set value	Start value~65Hz	This setting value is only available when the operating mode is "alarm"
setting time	0.2~36s	
Operating method during protection	Alarm/Trip/Shutdown	
High frequency protection		
Protection return set value	Return value~65Hz	
setting time	0.2~5s	
Protection return set value	45Hz~Return value	This setting value is only available when the operating mode is "alarm"
setting time	0.2~36s	
Operating method during protection	Alarm/Trip/Shutdown	



SB1 Shunt release button (prepared by the user) SB4 Reset button (prepared by the user) F Shunt release

SB2 Undervoltage button (prepared by the user) M Motor Q Undervoltage release or undervoltage
time delay release SB3 Closing button (prepared by the user) X Closing electromagnetic Y Remote reset
electromagnetic

Terminal description:


1# 2#: Release working power supply (must be connected to the power module)

3# 4# 5#: Fault tripping signal output

10# 11# : Communication interface

Auxiliary switch
(4NO+4NC/6NO+6NC/8NO+8NC)

辅助开关 (四开四闭/六开六闭/八开八闭)



12#13#, 14#15#, 16#17#, 18#19# respectively:

DO1, DO2, DO3, DO4 Signal contact output

20#: trip unit protective grounding

21#~24#: Voltage sampling, in sequence: N, A, B, C

25# 26#: External neutral transformer

27# 28#: Undervoltage release

29# 30#: Shunt release

31# 32#: Closing electromagnetic

33# 34# 35#: Charging motor



Note: 1. Terminal 1 # and 2 # cannot be directly connected to a DC220V/380V or DC110V/220V power supply. The voltage needs to be converted to DC24V through the power module to supply power to the trip unit.


2. The UEW6-2000 can only provide up to six changeover and six NO/NC.

7 Installation dimension

7.1 Installation dimensions of breakers


UEW6-2000 draw out





UEW6-2000抽屉式加长母线尺寸

UEW6-2000 draw out type extended busbar



UEW6-2000抽屉式短母线尺寸


UEW6-2000 draw out type short busbar

In(A)	a(mm)
630~800	10
1000~1600	15
2000	20

UEW6-2000 fixed type breaker


Cover center

柜门




Installation hole

面罩中心




Installation hole



UEW6-2000固定式加长母线尺寸

UEW6-2000 fixed type extended busbar




UEW6-2000固定式短母线尺寸

UEW6-2000 fixed type short busbar


In(A)	a(mm)
630~800	10
1000~1600	15
2000	20

UEW6-3200 draw out type breaker



UEW6-3200/2500A~3200A抽屉式母排尺寸

UEW6-3200/2500A 3200A draw out type busbar




UEW6-3200/1000A~2000A抽屉式母排尺寸

UEW6-3200/1000A~2000A draw out type busbar



UEW6-3200 fixed type breaker

Horizontal outgoing





Installation hole

Vertical outgoing



Installation hole

安装孔




N phase

Installation hole on the right
e base

UEW6-3200/2900A~3200A固定式水平母排尺寸


UEW6-3200/2900A~3200A fixed type horizontal busbar



le on the right of the base

UEW6-3200/2900A~3200A固定式垂直母排尺寸

UEW6-3200/2900A~3200A fixed type vertical busbar



ation hole on the right
base

(注: 上母排尺寸A为90mm, 下母排尺寸A为86mm)

(Note: The size A of the upper busbar is 90mm, and the size A of the lower busbar is 86mm)

UEW6-3200/1000A~2500A固定式母排尺寸


UEW6-3200/1000A~2500A fixed type busbar

UEW6-4000 draw out breaker

Horizontal outgoing

Cover center


Door




面罩中心


Installation hole

安装孔






UEW6-4000 fixed type breaker



(Note: The size A of the upper busbar is 90mm, and the size A of the lower busbar is 86mm)



Installation hole on the right of base

(注: 上母排尺寸A为90mm, 下母排尺寸A为86mm)

UEW6-4000/1000A~2500A固定式母排尺寸

Frame opening dimension


UEW6-4000/1000A~2500A fixed type busbar

7.1 门框开孔尺寸

UEW6-2000 抽屉式

UEW6-2000 fixed type

Coincident with the center of the cover




Breaker installation surface

UEW6-2000 固定式

UEW6-2000 fixed type


Coincident with the center of the cover



UEW5-3200/4000 抽屉式

UEW5-3200/4000 draw out type


Coincident with the center of the cover



UEW5-3200/4000 固定式

UEW5-3200/4000 fixed type


Coincident with the center of the cover



8 Safety distance


Draw out type

抽屉式



Fixed type

固定式



Minimum distance between breaker and cabinet wall or live parts

	To insulator mm		To metal body mm	
	A	B	A	B
Draw out type	0	0	60	60
Fixed type	0	0	60	60

9 Installation and Maintenance

■ Installation (refer to the previous chapter for the required dimensions for installation)

Before installation, check whether the working environment of the breaker meets the requirements

Before installation, check the insulation resistance of the breaker with a 500V megohmmeter. When the surrounding medium temperature is $20\text{ }^{\circ}\text{C} \pm 5\text{ }^{\circ}\text{C}$ and the relative humidity is 50%~70%, it should not be less than $10\text{M } \Omega$. Otherwise, it should be dried and used only when the insulation resistance meets the requirements.

When installing the breaker, its base should be in a horizontal position.

During installation, reliable grounding protection should be provided for the breaker. The grounding of the breaker should be clearly marked, and the breaker should strictly comply with the safety distance regulations.

After the circuit breaker is installed according to the relevant wiring diagram and confirmed to be correct, the following inspections and operational tests should be carried out before the main circuit is powered on (the drawer type circuit breaker places the circuit breaker body in the test position):

After the circuit breaker is installed according to the relevant wiring diagram and confirmed to be correct, the following inspections and operational tests should be carried out before the main circuit is powered on (the drawer out type breaker places the circuit breaker body in the test position):

Check if the operating voltage of the undervoltage, shunt release, closing electromagnetic, and charging motor is within the required range (if equipped with an undervoltage release, the undervoltage release should be energized first before the circuit breaker can be closed).

Firstly, manually charge and open, close the circuit breaker, and the circuit breaker should operate normally;

Then electrically charge and electrically open and close the breaker, which should operate normally; If equipped with an undervoltage release, it can make the undervoltage release to lose voltage or undervoltage, and the undervoltage release should be able to trip the breaker.

Note: When rock the body of the draw out type breaker to the "rocked in" position, the breaker must be opened first.

■ Inspection and maintenance

1. Regular inspection and maintenance. The time interval is once a year when installed in a normal environment, and generally once every six months when installed in a polluting environment; After a short circuit trip, immediate inspection and maintenance should be carried out to confirm that there are no faults before continuing operation.

2. Regularly clean the dust to maintain good insulation of the circuit breaker; At the same time, check if the electrical connection screws are loose;

3. Regularly inspect the contact system, mechanism, and accessories

Check the burning condition of the arc extinguishing cover and contact, and if the burning is severe, replace it. It is recommended to polish the surface of the dynamic and static contact points with fine sandpaper once a year to remove the surface oxide layer.

Check whether all fasteners are loose, and whether the limiting components have fallen or failed.

Check whether the voltage of each accessory is within the required range, and the operating performance of the accessory should meet its corresponding characteristic requirements.

When the breaker is operated for very few times or for a long time in the open or closed position, it is recommended to operate it once or twice a quarter

4. Inspection after short-circuit breaking

The inspection content is the same as the regular inspection of the contact system and mechanism, and the addition of flexible connections and welding parts, as well as the inspection of the arc extinguishing chamber, should be free of obvious damage, otherwise the damaged components need to be replaced. When the breaker reaches its electrical lifespan, it should be replaced or repaired in a timely manner.

■ Common faults and troubleshooting methods

No.	Fault	Reasons	Trouble shooting
1	The circuit breaker cannot be manually closed or opened	a. An undervoltage release is selected, and it is not powered on (or the power supply voltage is too low) b. After the trip unit trips, the red button on the upper part of the release panel does not reset c. Operating mechanism not charged d. Interlocking device in locked position.	a. Check if the wiring terminals of the circuit and secondary circuit are loose. Is the undervoltage release powered on. b. Press the reset button c. Manually (using the operating handle) or electrically to charge the mechanism d. Open the other breaker with which it is interlocking
2	The breaker cannot be charged electrically	The power supply of the electric motor is not connected (or the power voltage is too low)	Check if the wiring terminals of the circuit and secondary circuit are loose, and connect the power supply (the voltage of the charging motor should be greater than 85% U_e).

3	The circuit breaker cannot be electrically closed or opened	<p>a. The closing electromagnet and shunt release are not powered on (or the power supply voltage is too low)</p> <p>b. The reason same as above item 1: The circuit breaker cannot be manually closed or opened</p>	<p>a. Check if the wiring terminals of the circuit and secondary circuit are loose, and connect the power supply (the voltage of the closed electromagnet and the shunt release should be greater than 85% U_e and 70% U_e respectively)</p> <p>b. Trouble shoot the same as above item 1: The circuit breaker cannot be manually closed or opened</p>
4	Frequent tripping	<p>a. Overload operation on site caused overload protection tripping, and the overload thermal memory function failed to power off and clear in time.</p> <p>b. Parameter settings do not match load current</p> <p>c. Poor contact due to loose wiring of terminals in the secondary circuit of the undervoltage release</p>	<p>a. Power off once, or close the circuit breaker after 30 minutes</p> <p>b. Reset the protection parameters according to the load situation by professional personnel</p> <p>c. Check the circuit and tighten the secondary circuit wiring screws of the undervoltage release</p>
5	The crank of the draw out type breaker cannot be inserted into the working hole	Position locking are not unlocked on the cradle	Unlock the position locking on the cradle
6	The breaker cannot be moved inside the cradle, and the crank is stuck	<p>a. The unlock button on the cradle is not pressed down</p> <p>b. Foreign particle is stuck in the mechanism of the cradle</p>	<p>a. Press down the unlock button on the cradle</p> <p>b. Contact Hongfa aftersales</p>
7	The breaker body cannot be extracted from the cradle	<p>a. The breaker does not fully retract to the rocked out position</p> <p>b. Sliding plate is not unlocked</p>	<p>a. Rock the breaker in rocked out position</p> <p>b. Unlock the sliding plate</p>

Note: If the fault cannot be handled after checking according to the above table, please record the fault condition of the breaker in detail (or take pictures), product factory number, and other information in a timely manner to contact and negotiate for resolution.