



Interphase Barrier

Main

Range	UEW6
Product or Component Type	Interphase barrier
Mounting Type	fixed type
Range Compatibility	UEW6-1600

Complementary

Frame	1600
Description of Functions	It is installed between each phase busbar to increase the insulation strength between each phase and prevent short circuit between busbars.